


SMS FLATSCREEN FM ST

MANUAL



- GB – Instructions for Mounting
- DE – Montageinformation
- IT – Istruzioni per il montaggio
- ES – Instrucciones para el montaje
- FI – Asennusohjeet
- FR – Instructions de montage
- NL – Montagevoorschriften
- PL – Instrukcja montażu
- RUS – Инструкция по монтажу
- ARB – عربي - طريقة التركيب
- SE – Monteringsinstruktion
- GR – Πληροφορίες συναρμολόγησης









FS071003..071004
071005




Contents	
A	Aluminium Pillar (1x)
B	SMS Middle Unislide (1x)
C	Floor Stand (1x)
D	Swivel / Tilt Bracket (1x)
E	Plastic Cover (1x)
F	Screw M5x16 (4x)
G	Cables (Not included)
H	Plastic cover over cables
I	Allen Key (2x)





9



10

