









English

1. Mount the four arms to the disc.
2. Mount the projector to the arms. Use the supplied spacers, bolts and washers.
3. Mount the ball joint to the truss clamp. Use the supplied mounting material.
4. Mount the truss clamp to the truss system.
5. Mount the projector to the truss clamp by tightening the ball joint. Turn ball clamping ring to set the resistance of the adjustment.
6. Extra fixation of the ball joint can be obtained by using a screwdriver through the hole of the ball clamping ring and turning it tight. This same hole can be used for placing an optional anti-theft lock.

Nederlands

1. Monteer de vier armpjes aan de bracketschijf.
2. Monteer de projector aan de armpjes. Gebruik hier voor de meegeleverde afstandbussen, bouten en sluitringen.
3. Monteer de kogelkoppeling aan de trusshaak. Gebruik hiervoor het meegeleverde montage materiaal.
4. Bepaal de juiste positie van trusshaak en bevestig deze aan de truss.
5. De projector kan vervolgens worden opgehangen door het kogelgewricht aan te draaien.
6. Indien nodig kan er extra fixatie van de kogel worden verkregen door een schroevendraaier door het gat van de kogelklemring te steken en deze te gebruiken om de ring aan te draaien. Nadat de projector is gefixeerd kan door hetzelfde gat een hangslot worden gedaan.